

# WARNING

Install on  
SMARTWASTE



**NOT Recommended!**

(Unless reinforcing the shower base right over the entire SMARTWASTE)

We strongly Recommend use our  
SMC Self-supported shower base  
for SMARTWASTE installation

Install on  
SMARTPAN



Need to be used in conjunction with a SMARTSEAL



Under side of the shower base need to be fully  
supported up to the edge of the drain

We strongly Recommend use our  
SMC Self-supported shower base  
for SMARTPAN installation

\*AP shower base are to be installed by a qualified plumber. Failure to do so will void warranty. Installation does not meet our requirements will void warranty. A Certificate of Compliance from plumber will be required for any warranty claim

\*AP shower base are to be installed by a qualified plumber. Failure to do so will void warranty. Installation does not meet our requirements will void warranty. A Certificate of Compliance from plumber will be required for any warranty claim